




Software Update

Before installing any Wi-Pics Mobile! software updates, it is strongly recommended that you first perform a CLEAN RESET of your Pocket PC device.

Please follow the steps below to perform a CLEAN RESET and install your new *Wi-Pics Mobile!™* software.



Press and hold these **three buttons** simultaneously while inserting the stylus into the small hole in the bottom of the unit, press and release the **Reset button** (**you must continue to hold all three buttons until the green Windows Mobile screen is displayed**).

If the device has been properly reset, you will be prompted to do the following:

Tap screen to begin setup of Windows Mobile device.

- Align the Screen
- Select Skip
- Select your Time Zone
- Select the Date
- Enter the Time
- Enter a Password (SKIP RECOMENDED)

Next, it is recommended that you;

- Configure Wireless Settings (see page 31 in *Wi-Pics Mobile!™* User Guide)
- Configure Buttons (see page 37 in *Wi-Pics Mobile!™* User Guide)
- Adjust Backlight settings (see page 36 in *Wi-Pics Mobile!™* User Guide)
- Adjust Screen Orientation settings (see page 35 in *Wi-Pics Mobile!™* User Guide)

Re-install *Wi-Pics Mobile!™* Software (see page 12 in *Wi-Pics Mobile!™* User Guide)

Reconfigure Global, Data Association and Image Transmission Settings (see pages 16-25 in User Guide)

If you need assistance with any of the above, please contact our support group at 585-798-5973 or email us at support@unitedimaging.com

Wi-Pics Mobile!™

More than just another wireless solution

Powered by Idruna Software, Inc.